You are here: DD-WRT wiki mainpage / Scripting / SSH/Telnet & The CLI / ip command

This is an infant page. Clean it up and fill it with content!

#### **Contents**

- <u>1 Basic</u> <u>Usage</u>
- 2

**OBJECTs** 

• <u>3</u> <u>OPTIONS</u> • <u>3.1</u>

▼ <u>3.1</u> <u>family</u>

## **Basic Usage**

As always, things in [] are optional and I means or

```
ip [ OPTIONS ] OBJECT { COMMAND | help }
```

Ex: To get help on the *link* object, one would enter

```
ip link help
```

#### **OBJECTs**

Objects can be any of the following. (A short description of each should be added)

```
link
kkl
route
rule
neigh
tunnel
maddr
mroute
monitor
```

### **OPTIONS**

Options can either be the short or long version Ex: *ip -V* is the same as *ip -Version* 

```
-V[ersion]
-s[tatistics]
```

OPTIONS 1

```
-r[esolve]
-n[num tables]|
-f[amily]
-o[neline]
```

# family

Family itself can take additional options:

inet
inet6
ipx
dnet
link

family 2